

# Celectigo

Portable Automatic  
Liquid Pump  
User Manual

Scan the QR code below for a quick setup video, updated digital manual, guides, FAQs, and our social media accounts.



<https://celectigo.com/c6h>

# Index

A. Notice Before Use.....	4
B. Safety Warnings.....	5
C. Product Overview.....	6
D. Setup.....	7
E. Operations.....	8
F. Maintenance.....	9
G. Specifications.....	10
H. Warranty & Support.....	11

## A. Notice Before Use

1. **Do not use with corrosive liquids or drinking water.** This pump is intended only for transferring gasoline, water, oil, and other non-corrosive liquids.
2. **Proper Use:** Use only as intended. Do not pump used, dirty oil.
3. **Temperature Warning:** Do not use the pump if it is hot.
4. **Secure Connections:** Verify all connections are tight before use to eliminate leaking.
5. **Pump Orientation:** Do not turn the pump upside down after use.

## B. Safety Warnings

1. **Explosion Hazard:** When pumping gasoline or flammable liquids, ensure adequate ventilation. Avoid sparks and do not use near open flames or heat sources.
2. **Wear Safety Gear:** Always wear ANSI-approved safety goggles and heavy-duty, chemical-resistant gloves during use.
3. **Keep Away from Children:** This product is not a toy. Do not allow children to play with or near this item.
4. **Battery Safety:** Remove batteries when not in use. Do not mix old and new batteries, or different types. Ensure batteries are positioned correctly and do not use swollen or leaking batteries.
5. **User Condition:** Do not operate when tired or under the influence of drugs or medication.
6. **Inspection:** Inspect before every use; do not use if parts are loose or damaged.
7. **Environmental Compliance:** Follow all local, state, and federal laws regarding the disposal of oil and gasoline.

## C. Product Overview

- **Switch:** Controls the power (ON/OFF) for the pump.
- **Battery Case:** Holds 2x D cell 1.5V (LR20) batteries.
- **Suction End:** Insert into the liquid to be transferred.
- **Discharge Hose:** Directs the liquid into the receiving container.
- **Lock Catch:** Secures the trigger in place for continuous operation.
- **Nozzle:** Controls the flow of liquid into the delivery hose.

## D. Setup

1. **Insert Batteries:** Open the battery case and insert 2x D cell 1.5V (LR20) batteries, ensuring correct polarity.
2. **Attachment Installation Steps:**
  - Loosen the elastic fastener and fit it onto the mouth of the delivery hose.
  - Insert the end of the nozzle into the delivery hose.
  - Secure the hose and nozzle in place, tighten the clamp, and complete the installation.
3. **Deploy Suction Tube:** Insert the suction tube as far as possible into the liquid to be transferred.
4. **Final Check:** Ensure all connections are tight and the suction tube is fully submerged.

## E. Operations

1. **Insert the Suction Tube:** Ensure the suction tube is as far as possible into the liquid to be transferred.
2. **Position the Nozzle:** Place the nozzle into a receiving container, ensuring it is lower than the battery housing.
3. **Turn ON:** Flip the ON/OFF switch to ON. Ensure the battery compartment remains sealed during operation.
4. **Operate the Nozzle:** Pull the trigger lever on the nozzle to start transferring liquid. Fully release the trigger lever to cut off flow.
5. **Avoid Running Dry:** Do not run the unit dry. Make sure the suction tube is fully submerged in the liquid before turning on.
6. **Turn OFF:** When the transfer is complete, turn the switch OFF.
7. **Post-Use:** Do not turn the pump upside down after use. Rinse the unit with water, wipe it dry, and remove the batteries. Store in a clean, dry location out of reach of children.



## F. Maintenance

### 1. Before Each Use:

- Inspect for loose hardware.
- Check for misalignment or binding of moving parts.
- Look for cracked or broken parts.
- Address any condition that may affect safe operation.

### 2. After Each Use:

- Rinse the pump with water.
- Wipe the unit dry after cleaning.
- Remove batteries and store the pump in a clean, dry location out of reach of children.

## G. Specifications

- Power Source: 2x D cell 1.5V (LR20) batteries.
- Materials: Heavy-duty plastic with chemical-resistant components.
- Liquid Types: Gasoline, water, oil, and other non-corrosive liquids.
- Safety Standards: ANSI-approved components for user protection.
- Operating Conditions: Use only in well-ventilated areas, away from flames or heat sources.

## H. Warranty & Support

Thank you for choosing Celectigo. We are dedicated to providing innovative and convenient products for an enhanced lifestyle. This Product Warranty Agreement ("Warranty") applies to items purchased directly from Celectigo.

### **Warranty Duration:**

All products sold by Celectigo come with a standard one (1) year warranty from the date of purchase, unless stated otherwise.

### **Warranty Coverage:**

During the warranty duration, Celectigo assures that the product will be free from defects in materials and workmanship when used under regular conditions.

### **Exclusions:**

This Warranty does not cover the following:

- Damages due to misuse, neglect, or deviation from user instructions.
- Damages from natural disasters such as floods, fires, or accidents.
- Unauthorized repairs, modifications, or disassembling.
- Cosmetic damages like scratches, dents, or broken parts.

## H. Warranty & Support (Continued)

### **Filing a Warranty Claim:**

- Reach out to Linkstyle Customer Support providing your proof of purchase, product details, and a comprehensive description of the issue.
- Our team will evaluate the claim and, if required, provide return shipping instructions.
- If the product is confirmed defective, Celectigo, at its discretion, will repair or replace the item.

### **Limitation of Liability:**

Celectigo liability is strictly limited to the repair or replacement of the product. Under no circumstances will Celectigo be liable for any indirect, incidental, or consequential damages. The total liability shall not exceed the original purchase price of the product.

## H. Warranty & Support (Continued)

### **Warranty Transferability:**

This Warranty is solely for the original purchaser and cannot be transferred.

### **Governing Law:**

This Warranty is governed by the laws of the country/state of purchase.

### **Disclaimer:**

Apart from what's stated here, no other express or implied warranties apply, including implied warranties of merchantability or suitability for a specific purpose.

For any queries or concerns regarding our products or this Warranty, reach out to us at [contact@celectigo.com](mailto:contact@celectigo.com).

# Celectigo

Convenient. Creative. Curated.