



Smart Wallet Tracker Card
User Manual

Scan the QR code below for a quick setup video, updated digital manual, guides, FAQs, and our social media accounts.



<https://celectigo.com/c3h>

Index

A. Notice Before Use.....	4
B. Getting Started.....	5
C. Adding Your Smart Card.....	6
D. Locating Your Smart Card.....	7
E. Finding Smart Card When Out of Range.....	8
F. When Your Smart Card is Lost.....	9
G. Resetting Your Smart Card.....	10
H. Regulatory Compliance and Safety.....	11
I. Warranty & Support.....	14

A. Notice Before Use

1. Charging

Use standard wireless charging equipment to charge the Smart Card wirelessly. A red light will remain on while charging and will turn off once fully charged.

2. Unwanted Tracking Detection

If your iPhone detects that an unknown Smart Card is traveling with you, you will receive a notification. A sound will play, allowing you to locate the device.

Note: These alerts activate only when a Smart Card is not connected to its owner's phone, so a partner's Smart Card will not trigger a sound if they are with you.

B. Getting Started

Power On/Off

Press Function Button once to turn on the device. It will beep once to indicate it is powered on.

To power off, hold the button for 3 seconds. It will beep 2 times to indicate it is powered off.

Check for Updates

To use the Apple Find My app to locate the Smart Card, be sure to keep the app updated to the latest version. iPadOS and MacOS are recommended.

C. Adding Your Smart Card

Step 1: Open the App

1. Launch the Find My app on your supported iPhone or iPad.
2. Ensure that notifications are enabled for the app.

Step 2: Connect Your Item Locator

1. Power on your Smart Card.
2. In the Find My app, select the Items tab.
3. Tap Add Item and then choose Other Supported Items.
4. Once your Item Locator is detected, tap Connect.
5. Select a recognizable name and an emoji for your Smart Card, then tap Continue.
6. When prompted to confirm adding your Smart Card to your Apple ID, tap Continue.
7. Tap Finish to complete the setup.

D. Locating Your Smart Card

Locate Smart Card When Nearby

1. Open the Find My app and go to the Items tab.
2. Select your Smart Card from the list.
3. Tap Play Sound to make your Smart Card emit a beep.
4. Once you locate it, tap Stop Sound to silence the beeping.

Find Smart Card's Last Known Location

1. Open the Find My app and go to the Items tab.
2. Select your Smart Card from the list.
3. The last known location of your Smart Card will display on the map, marked by the emoji chosen during setup.

E. Finding Smart Card When Out of Range

Option 1: Enable "Notify When Left Behind"

1. Open the Find My app and go to the Items tab.
2. Select your Smart Card from the list.
3. Under Notifications, enable the Notify When Left Behind toggle.
4. You will receive a notification if you leave your Smart Card behind and it is out of range of your device.

Option 2: Enable "Notify When Found"

1. Under Notifications, enable the Notify When Found toggle.
2. When your Smart Card is detected by another Find My-enabled device, you will receive a notification with its updated location.

Note: Notify When Found can only be activated when your Smart Card is out of range.

F. When Your Smart Card is Lost

Enable "Lost Mode"

1. Open the Find My app and go to the Items tab.
2. Select your Smart Card from the list.
3. Under Lost Mode, tap Enable.
4. A screen with details about Lost Mode will appear; tap Continue.
5. Enter your phone number or email address, then tap Next.
6. Optionally, add a message that will be shared with the person who finds your Smart Card.
7. Tap Activate to enable Lost Mode.

Notes:

- When Lost Mode is enabled, Notify When Found is automatically activated.
- Enabling Lost Mode locks your Smart Card, preventing it from being paired with a new device.

G. Resetting Your Smart Card

Step 1: Remove Smart Card from the Find My App

1. Open the Find My app and go to the Items tab.
2. Select your Smart Card from the list.
3. Ensure that Lost Mode is disabled.
4. Scroll to the bottom of the screen and tap Remove Item.
5. A confirmation summary will appear; tap Remove to confirm.

Step 2: Factory Reset Your Smart Card

1. After successfully removing the Smart Card from the Find My app, press the function button on your Smart Card four times rapidly. You will hear a beep with each press.
2. On the fifth press, hold the button until you hear a continuous ringing chime.
3. Your Smart Card is now reset and ready to be paired with a new device.

H. Regulatory Compliance and Safety

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: The manufacturer and retailer are not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

This device has been evaluated to meet general RF exposure requirements and can be used in portable exposure conditions without restriction.

H. Regulatory Compliance and Safety (Continued)

FCC Radiation Exposure Statement:

The power output of this device is low enough that no RF exposure calculation is needed.

This equipment has been tested and complies with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential setting. This equipment generates, uses, and can emit radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

H. Regulatory Compliance and Safety (Continued)

There is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be confirmed by turning the equipment off and on, users are encouraged to attempt the following corrective measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and the receiver.
- Connect the equipment to an outlet on a different circuit from the receiver.

I. Warranty & Support

Thank you for choosing Celectigo. We are dedicated to providing innovative and convenient products for an enhanced lifestyle. This Product Warranty Agreement ("Warranty") applies to items purchased directly from Celectigo.

Warranty Duration:

All products sold by Celectigo come with a standard one (1) year warranty from the date of purchase, unless stated otherwise.

Warranty Coverage:

During the warranty duration, Celectigo assures that the product will be free from defects in materials and workmanship when used under regular conditions.

Exclusions:

This Warranty does not cover the following:

- Damages due to misuse, neglect, or deviation from user instructions.
- Damages from natural disasters such as floods, fires, or accidents.
- Unauthorized repairs, modifications, or disassembling.
- Cosmetic damages like scratches, dents, or broken parts.

I. Warranty & Support (Continued)

Filing a Warranty Claim:

- Reach out to Linkstyle Customer Support providing your proof of purchase, product details, and a comprehensive description of the issue.
- Our team will evaluate the claim and, if required, provide return shipping instructions.
- If the product is confirmed defective, Celectigo, at its discretion, will repair or replace the item.

Limitation of Liability:

Celectigo liability is strictly limited to the repair or replacement of the product. Under no circumstances will Celectigo be liable for any indirect, incidental, or consequential damages. The total liability shall not exceed the original purchase price of the product.

I. Warranty & Support (Continued)

Warranty Transferability:

This Warranty is solely for the original purchaser and cannot be transferred.

Governing Law:

This Warranty is governed by the laws of the country/state of purchase.

Disclaimer:

Apart from what's stated here, no other express or implied warranties apply, including implied warranties of merchantability or suitability for a specific purpose.

For any queries or concerns regarding our products or this Warranty, reach out to us at contact@celectigo.com.

Celectigo

Convenient. Creative. Curated.